Use 1*18650 Battery

If you use 1*18650 battery
Please insert the transparent casing first, then insert the battery with positive ⊕ terminals facing forward and replace end cap.



1 2

Attention

Please remove the plastic protective covering from battery before use .

Use 3*AAA Batteries

If you want to use 3*AAA batteries
Please insert the batteries into the battery holder first, then put the battery holder positive end and replace end cap.



1 2

Operation

Power on/off: Press the button into 100% end. And there is a clicking sound to be heard.

Model selection: Gently press the button into about 50% end. And there is no clicking sound.

High › Medium › Low › Strobe › SOS

Adjustable focus: Stretch to adjust its focus



Charging

If you bought the flashlight with battery and charger from alldaymall, please refer below tips.

Please Insert the battery in the charger with the correct direction(based on the mark to position the positive ⊕ and negative ⊖ terminal)



Red indicating light means charging and Green indicating light means fully charged.



Special features: Reverse polarity protection

Most of the LED light will be burned if the positive and negative ends are in the wrong direction when inserting battery, but for this one, it just won't light, and will work as well if inserting the battery correctly later.

Maintenance

- Gently blow away any dust or debris on the lens (or use a soft lens brush).
- To remove dirt or fingerprints, clean with a soft cotton cloth, rubbing in a circular motion. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage.
- For a more thorough cleaning, photographic lens tissue and photographic-type lens cleaning fluid or isopropy alcohol may be used, always apply the fluid to the cleaning cloth-never directly on the lens.

Warning

- Please do not irradiate it to human eyes, especially for children.
- Do not over-charge or over-discharge the batteries
- Strongly suggest using the protected battery to protect its performance
- Remove batteries if not in use for long period
- Do not place activated flashlight against combustible material or any portion of the human body
- Do not mix old and new batteries or ones with different types to prevent recharging problems
- Make sure the positive and negative ends in the correct direction when inserting batteries
- Do not meddle with the head of torch or separate the reflector and the bulb.
- After long time lightening, please don't touch its glass to avoid scald your hands.

Warranty

- 365-day warranty: Free replacement can be requested based on quality issues within one year (The customer will need to cover shipping fees both ways).
- 30-day Money Back Guarantee: If you are not satisfied with the item within 30 days after receiving it, you can claim returns service for refund or exchange.
- This warranty doesn't cover damages caused by misuse, improper handling, installation, or maintenance provided by someone other than Alldaymall.

alldaymall

Flashlight
User Manual